

Radiotracers for micro-measurement of wear (Thin Layer Activation)

Dr. Martin Jech



Austrian Center of Competence for Tribology,
Viktor-Kaplan-Str. 2, 2700 Wiener Neustadt, Austria


International Atomic Energy Agency Scientific Forum

ATOMS IN INDUSTRY


Radiation Technology for Development

15–16 September 2015, Vienna, Austria

Reduction of wear for increasing service time




Direct measurement – loss of activity of specimen



- + continuous
- + real time
- + easy to install
- ~ good sensitivity


Indirect measurement – tracer technology increase of wear particles in oil



- + continuous
- ~ little time shift with oil transport
- ~ moderate effort to install
- + very high sensitivity





Bulk activation



Whole component irradiated with neutrons in nuclear reactor

- + high number of gainable isotopes
- ~ easier wear calculation due to constant concentration
- handling and waste

Thin layer or surface layer activation (TLA / SLA)



Surface of component irradiated by ions (protons or deuterons) in cyclotron


- + activity, where wear happens
-> higher sensitivity
- + selection of isotopes by beam parameters



Bulk and Surface Layer Activation (SLA) Heavy Duty On-Highway Cycle






©Copyright Southwest Research Institute, San Antonio, Texas, USA © 2015



TLA – irradiation and gained isotopes



©Copyright Institute for Nuclear Research,
Hungarian Academy of Sciences
ATOMKI, Debrecen, Hungary




T.Sauvage, L.Vincent, G.Blondiaux

TLA2L – free tool for calculating gained isotopes and depth profile




Developed 2010 by S. Takacs,
Atomki, Debrecen, Hungary

Public resource <https://www-nds.iaea.org/TLA/>






- + use in MS Excel XP or higher
- + provides specific activity in depth
- + contains database of known reactions
- + contains database of corresponding cross-sections



Cam and tappet wear measurement




©Copyright RTM Activation at MIZ, Karlsruhe, Germany



Labeled Areas on Cams Co-57

Labeled Areas on Tappets Co-56




Free Handling Limit (Council Directive 96/29/EURATOM)

Pros:

- Lower activities (environment, personal, waste handling)
- No license is needed
- Easier, cheaper delivery and storage
- Cheaper activation (shorter beam time)
- Better public acceptance

Cons:

- High accuracy only in combination with TLA (activity in surface layer)





Jech M., et al.: wear measurement at nanometer scale, Viennano'09

Wear of large gas engines affected by aging of engine oil




Lubricant	Hours of use [h]
Lubricant 1	0
Lubricant 2	~650
Lubricant 3	~1100
Lubricant 4	~1750





Jech M., Wopelka Th., Franek F.: nVCT - wear measurement at nanometer scale, Conference Proceedings, Viennano'09, Österreichische Tribologische Gesellschaft, 18.-20.03.2009, ISBN 978-3-901657-32-0, pp 115-120, 2009.




Wear of internal combustion engine affected by ethanol (bio) fuel



Engine



Tribometer



Radioactive isotopes for wear measurement

Production of radioactive isotopes through


- bulk activation
- thin layer activation (TLA, SLA)

Most used: indirect (tracer) measurement together with TLA

- wear of engine components: cylinder bore, piston ring, cam and tappet, bearings ...
- investigation of effects influencing wear and corrosion
- monitoring of corrosion or wear at inaccessible places

Benefit

- well established real time wear measurement
- highest sensitivity of all measurement techniques (nm/h)
- continuous observation (monitoring of transients)



Thank you!

